



|                          |   |
|--------------------------|---|
| <b>Hazards</b>           |   |
| <b>Tools/Equipment</b>   |   |
| <b>Employee Group(s)</b> | Facilities Management – Central Heating Plant |

**Required PPE:**



Safety Shoes

**SAFE WORK PRACTICES**

- Do not perform the procedure or operate the equipment until you have been appropriately trained and authorized to do so by your supervisor.
- Inspect required personal protective equipment (PPE) and replace if required.

**PROCEDURE**

- PLC cabinet wiring panel key switch in hallway
  - 1) Key switch – turn to Program mode
  - 2) Shut power off by opening power supply breaker inside cabinet 10 – 15 seconds
  - 3) Turn power back on
  - 4) Key switch return to RUN
  - 5) Restart steam flow program.

Login – klatimer

Password – none required

---

*NOTE: All PPE, tools and equipment shall be used in accordance with provincial OH&S legislation, manufacturer's specifications, applicable standards and codes of practice.*