



<b>Hazards</b>	fires, burns, electrical
<b>Tools/Equipment</b>	
<b>Employee Group(s)</b>	Facilities Management - Carpentry

**Required PPE:**



Eye  
Protection



Gloves



Respirator



Safety  
Shoes

**SAFE WORK PRACTICES**

- Do not perform the procedure or operate the equipment until you have been appropriately trained and authorized to do so by your supervisor.
- Inspect required personal protective equipment (PPE) and replace if required.
- Do not wear loose-fitting clothing, dangling jewelry, etc.
- Always be aware of surroundings.
- Ensure fall protection plan is in place.
- Ensure hot work is done as noted in Hot Work Program.

**PROCEDURE**

1. The gun is used for heating roofing membranes only (takes the place of a torch).
2. Do not use in damp weather.
3. Inspect the area for flammable material before starting.
4. Avoid breathing in vapors.
5. Do not touch hot element.
6. Make sure switch is off when plugging in extension cord.
7. After job is completed, turn unit on low for 10 minutes before shutting it completely off.

---

*NOTE: All PPE, tools and equipment shall be used in accordance with provincial OH&S legislation, manufacturer's specifications, applicable standards and codes of practice.*